IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Always stake or weight down your E-Z UP®. Do not use in any
 potentially windy or rainy weather. Wind and rain can damage the
 E-Z UP® Instant Shelter® and may also result in injury to you or
 others. Therefore, do not rely on shelter for protection in heavy or
 prolonged rain storms.
- The E-Z UP® Instant Shelter® is designed as a temporary shelter. Do not leave up for extended periods.
- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Do not use shelter in a lightning storm.
- Do not leave your E-Z UP® Instant Shelter® unattended.
- Keep all flame and heat sources away from fabric top. Do not build fires within shelter enclosure.

Fire resistant - meets NFPA-701 requirements.

CARE AND MAINTENANCE

For long lasting durability and the best possible protection for your E-Z UP® Instant Shelter®. follow these E-Z care and maintenance instructions:

- Use a mild soap (not detergent) and plenty of water for top cleaning.
- Let the E-Z UP® top and frame dry completely before closing or storing to avoid mildew.
- Frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top.
- Use a seam sealer if top leaks or drips water. Available at most sporting goods and hardware stores.
- Slightly tighten bolts if frame becomes loose.

For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at WATATA PAUP GOM

Ask about our other E-Z UP® Instant Products™

Covered under one or more of the following patents: 4,607,656; 4,924,896; 5,244,001; 5,421,356; 5,485,848; 5,490,533; 5,511,572: 5,632,972; 5,632,973: 5,794,546; 5,797,412; 5,813,425; 5,865,127; 5,921,260; 5,934,301; 6,041,800; 6,070; 6,044; 6,076; 312; 6,129,102; 6,138,702; 6,129,910; 6,230,792; 6,240,904; 6,431,193; 6,439,251; 6,601,599; 9,5704390; 94/2354; 91461; 132167; 95/0693; 95/6140; 95/6141; 84107895; 684,978; 2123096; 190486; 289754; 215344; 701077; 2128935; 2949648; 48648; DE 695 10 919 12; W096/03561. International Design Registration No. DM/009515 Benelux Design Registration No. 16959-04. Other US and foreign patents pending. © Copyright 2004 International E-Z UP, Inc. USA. All rights reserved.

PRODUCT WARRANTY

INTERNATIONAL E-Z UP, INC., manufacturer of the E-Z UP® Instant Shelter™, warrants to the original purchaser who provides a dated sales receipt, each part of the E-Z UP® Instant Shelter™ to be free from defects in material or workmanship for a period of **TWO YEARS** after the date of original purchase. This warranty applies only for normal and expected uses, as determined by the manufacturer. INTERNATIONAL E-Z UP, INC.'s obligation and liability under this warranty is limited to the repair or replacement (at its option) of the product or its parts, after its own review and examination.

RETURN ADVISORY - Before returning any part or product to INTERNATIONAL E-Z UP, INC. or its designated representative, please phone or write to obtain specific return shipping instructions. All shipping costs must be prepaid, and INTERNATIONAL E-Z UP, INC. is not responsible for products damaged in transit.

CONDITIONS - This warranty shall be void as to any product which has been altered or modified in any manner. This warranty does not apply to damages caused by wind, rain, or other forces of nature, not to accidental or deliberated damage of the product, nor to use of the product that does not conform with the product instructions.

This warranty is provided in lieu of all other warranties, expressed or implied.

We Make Life E-Z!™ INTERNATIONAL E-Z UP, INC.

1650 Iowa Avenue, Suite 200, Riverside, California 92507 (909) 426-0060 ● Fax (909) 426-0063

www.ezup.com

Customer Service Hot Line

800-SHADE ME

E-Z UP®
INSTANT SHELTER®



"Sets Up in Seconds!™"

DUMEN

10' x 10'

Take time to learn how to provide years of durable and safe use from your E-Z UP® Instant Shelter®. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



(800) SHADE ME www.ezup.com

WHAT'S IN THE BOX

Please read each step before you attempt to set up. Save these instructions for future reference.

- 10' x 10' Frame
- 300 x 300 Polyester Top w/ Silver Coating
- Roller Bag
- 4 Piece Stake Kit
- Sun Catcher™

How To SET UP

Important: First time top attachment is required.

The first time you set up your Instant Shelter®, the top must be attached to the frame with Velcro®. After performing Step 1 below, unfold the top and attach the top to the

frame by matching Velcro® strips on the top with the Velcro® strips located just below the corner caps on each leg (see illustration 1). Push the Velcro® firmly together.


Attach Velcro® corners here.



Illustration 1



1. Place your E-Z UP® frame in the center of area to be sheltered. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' length.



2. Grasp the top and bottom of diamond-shaped area of trusses near "open" stickers. Slightly lift shelter up and push hands together while stepping backwards until shelter is fully opened. Be careful not to pinch fingers or pull backwards too hard as trusses will bend.



3. Engage auto slider at each corner by pushing up on slider with one hand while pushing down on top of leg with other hand. Snap button will engage in hole. Repeat step on remaining legs.



4. Lift two adjacent outer legs and pull out inner legs until snap button locks.



5. Attach the two Velcro® side strips located at the top of the center truss diamond on each side. Wrap the Velcro® strips around the truss assemblies, match Velcro® strips and press firmly together. Lift remaining outer legs and pull out inner legs until snap button locks.



6. Choose different height option by depressing snap button with your partner and lifting shelter until next snap button locks. Use stakes provided to secure.





1 • With a partner, lift adjacent outer legs slightly, depress snap button and telescope inner legs into outer legs. Repeat on remaining legs.



2. Release auto slider at each corner by first lifting hem of top. With one hand, push up on truss near slider to remove the weight of the shelter from snap button. Depress snap button and push slider down.



3. With partner on opposite side, grasp top and bottom of diamond-shaped area of trusses, near "close" stickers, and slightly, lift up. Shake shelter slightly, pulling hands apart, while stepping towards partner until shelter is 3/4 closed.



4. Grasp adjacent outer legs and push shelter together until fully closed. Be careful not to pinch fingers! Do not push hard. Place shelter in roller bag.